


Operating Instructions for T8

The Torgoen T8 model has three separate independent movements. In fact you have three separate watches with three separate batteries.

WARNING: Because of this, batteries may run out at different times. It is recommended to change all 3 batteries when the first movement's battery runs out.



IMPORTANT: All 3 movements are regular 12 hour movements and you may set them as you wish to three different time zones anywhere in the world. There is no indication of AM or PM in any of the separate movements, just like any regular analog watch. The printing on the dial gives you a *suggestion* for time zone settings such as LOCAL TIME (main), GMT and TIME AT DESTINATION.

To set the time on the main watch pull crown A all the way out (2 outward clicks) and turn until the desired time. Make sure the hands are set correctly to AM or PM time, so that the date would not change at noon instead of midnight. To do that simply turn the hands past 12 o'clock and observe if the date changes or not. To set the date, pull out crown A one position outward and turn until the desired date is displayed.

To set the time of the two other movements, simply pull out the crown adjacent to each of the movements and set the time to desired time zone.